

STIGA


VILLA CLASSIC (1998)

13-2855-22

Spare parts list **Reservdelar** **Repuestos** **Ersatzteile** **Pièces détachées** **Reserve onderdelen** **Catalogo ricambi**


- Use ST. S.p.A. Genuine Spare Parts specified in the parts list for repair and/or replacement.
- The contents described in the parts list may change due to improvement.
- The drawings of the spare parts are only indicative And might Not represent the part in question exactly.
- The indications "right" - "left" - "front" - "rear" refer to the position of the operator when using the machine.
- When placing orders of parts for repair And/Or replacement, make sure that the illustrated parts list Is the one applying to the machine's year of manufacture, as shown on the identification plate attached to the machine.

All rights reserved. No part Of this material may be reproduced Or transmitted, in any form Or by any means, electronic Or mechanical, including photocopying, recording Or by any information storage And retrieval system, without permission in writing from ST. S.p.A.




Frame Bodywork

Ref.nr.	Antal	Komponentkode	Beskrivelse	Noter	From	Op til
1	1	1134-3800-01	Seat Bracket-Yellow			
2	5	9739-0831-22	Nut			
3	3	9959-0816-16	Screw	L = 16 mm		
4	1	9997-0855-12	Screw	L = 55 mm		
5	1	9959-0825-16	Screw	L = 25 mm		
6	1	1134-1595-02	Tube			
7	2	1134-2849-01	Rubber Hose (30 Mm)			
8	2	9403-0015-70	Plug			
9	2	9739-0831-22	Nut			
10	2	9959-0816-16	Screw			
11	2	9997-1055-12	Screw			
13	1	1134-3799-01	Cover			
14	4	9849-8013-16	Screw			
20	1	1134-3819-01	Floor Mat			
30	1	1134-2856-01	Engine Hood Yellow			
31	1	9948-0616-16	Screw			
32	1	9699-0060-02	Washer			
33	1	1134-3643-01	Nut			
34	2	9405-0029-00	Knob			
35	3	9632-0516-00	Pop Rivet			
36	1	1134-9028-01	Rubber Strap (3 Pcs)	Sats 3 st/kit of 3		
37	1	9699-0054-02	Washer			
38	2	9699-0087-02	Washer			
39	2	9849-8013-16	Screw			
40	1	1134-2855-01	Engine Cover (Black)			
41	1	1134-2267-01	Guarding Net			
99	1	1134-3557-01	Label Kit			




Engine

Ref.nr.	Antal	Komponentkode	Beskrivelse	Noter	From	Op til
1	4	9747-0831-02	Lock Nut			
2	4	9997-0840-16	Screw			
20	1	1134-1364-02	Spacer Ring			
21	1	9600-0250-00	Key			
40	1	1134-1975-01	Throttle Cable			
41	1	9403-0035-10	Knob			
42	2	9849-8009-16	Screw			




Power take-off

Ref.nr.	Antal	Komponentkode	Beskrivelse	Noter	From	Op til
1	1	1134-1633-01	Engine Belt Pulley			
10	1	1131-1497-01	Brake Spring			
11	1	1134-0022-00	Control Rod			
12	1	1134-0027-01	Control Lever			
13	1	1134-2453-01	Locking Pawl			
14	1	1134-0143-00	Washer			
15	1	1134-0153-00	Handle Gear Shifter			
16	1	1134-0583-00	Knob			
17	1	1134-1972-01	Disengaging Lever			
18	2	9672-0004-02	Starlock			
20	2	9699-0025-02	Washer			
21	1	9739-0831-22	Nut			
22	1	9847-8016-16	Screw			
23	1	9959-0820-16	Screw			
30	1	1134-3512-01	Brake Lever			
31	1	1134-3510-01	Spacer			
32	1	9699-0056-02	Washer			
33	1	1134-3443-01	Brake Spring			
40	1	1134-3053-01	Tension Roller			
41	1	1134-1023-00	Brake Spring			
42	1	1134-1438-02	Tensioning Arm			
43	1	1134-1647-01	Belt Stirrup			
44	1	1134-1888-01	Spacer			
45	1	1134-1935-01	Link Rod			
46	1	1134-9010-01	V-Belt	= 9585-0053-00		
47	2	9699-0028-02	Washer			
48	1	9699-0062-02	Washer			
49	1	9739-0831-22	Nut			
50	1	9747-0831-02	Lock Nut			
51	1	9997-0845-12	Screw			
52	1	1131-1506-00	Spring			
53	1	9675-0011-00	Starlock			
54	1	9699-0090-02	Washer			
55	1	1134-1838-01	Tension Arm Bracket			
56	1	9696-0013-01	Washer			
57	1	9699-0056-02	Washer			
58	1	9739-0831-22	Nut			
59	1	9997-0855-12	Screw			
60	1	1134-1866-01	Tensioning Arm Compl			
61	1	1134-3043-01	Tension Roller			
62	1	9997-1050-16	Screw			
63	1	9739-1031-22	Nut			
64	1	1134-1322-01	Tensioning Wheel Spring			
65	1	1134-1486-01	Double V-Belt Pulley			
69	1	1134-9031-01	V-Belt	= 9585-0072-00		
70	1	1134-1839-01	Shaft			
71	1	1134-1569-01	Belt Guide			
72	2	9699-0035-02	Washer			




Power take-off

Ref.nr.	Antal	Komponentkode	Beskrivelse	Noter	From	Op til
73	1	9997-1080-12	Screw			
74	1	1134-3783-01	Bracket			
75	2	9959-0816-16	Screw			
76	2	9739-0831-22	Nut			




Clutch Brake

Ref.nr.	Antal	Komponentkode	Beskrivelse	Noter	From	Op til
1	1	1134-1633-01	Engine Belt Pulley			
2	1	9987-5338-12	Screw			
11	1	1134-3832-01	Tension Arm			
12	1	1134-9027-01	Tension Roller (Black)			
13	1	1134-9008-01	V-Belt	= 9585-0050-00		
14	1	9739-1031-22	Nut			
15	1	9997-1030-16	Screw			
16	1	1134-1949-01	Spring			
17	1	1134-0240-00	Screw			
18	1	9696-0013-01	Washer			
19	1	9699-0037-02	Washer			
20	1	9699-0090-02	Washer			
21	1	9739-0831-22	Nut			
30	1	1134-1849-01	Belt Pulley			
31	1	9650-0016-04	Circlip			
32	1	1134-1795-01	Belt Stirrup			
33	1	9699-0090-02	Washer			
40	1	1134-3801-01	Pedal			
41	1	1134-1927-01	Bearing			
42	2	9898-0635-12	Screw			
43	2	9739-0631-22	Nut			
44	1	1134-3633-01	Spring			
45	1	1134-3829-01	Control Rod			
46	1	1134-2138-01	Eye Bolt			
47	2	9747-0831-02	Lock Nut			
48	2	9739-1031-22	Nut			
49	1	9595-0208-00	Locating Pin			
50	1	1134-3817-01	Spring			
51	2	9699-0035-02	Washer			
52	1	1134-3809-01	Brake Rod			
53	1	9598-0002-02	Elastic Pin			
54	1	1134-3802-01	Parking Brake Lever			
55	1	1134-3808-01	Knob			
56	1	1134-0240-00	Screw			
57	1	9699-0069-02	Washer			
58	1	9694-0001-00	Washer			
59	1	9739-0831-22	Nut			
60	1	4231-0013-00	Spring			
70	1	1134-0139-01	Belt Guard			
71	1	9699-0090-02	Washer			




Transmission

Ref.nr.	Antal	Komponentkode	Beskrivelse	Noter	From	Op til
1	1	1134-3820-01	Sprocket			
2	1	1134-3823-01	Spacer			
3	1	9739-0831-22	Nut			
4	1	9997-0855-12	Screw			
5	1	1134-1942-01	Screw			
6	1	9747-0831-02	Lock Nut			
7	2	1134-1561-01	Lever			
8	1	1134-3823-01	Spacer			
9	1	9739-0831-22	Nut			
10	1	9997-0855-12	Screw			
11	1	9500-9949-00	Gear Box 781B	19	Peerless 781B	
12	4	9988-3619-16	Screw			
13	1	9589-0008-02	Chain w. chain lock			
14	1	9589-0504-00	Chain Fastener			
15	1	9600-0050-00	Key			
16	1	1134-1694-04	Differential		Peerless 100-019B	
17	1	1134-1691-02	Sprocket			
18	4	9743-3621-32	Nut			
30	2	1134-3176-02	Rim			
32	2	9545-0116-00	Tyre		16 x 7.50-8	
33	2	9545-0500-00	Valve Assy.			
34	2	1134-0341-01	Washer			
35	2	1134-1348-01	Screw			
36	2	9743-3721-32	Nut			
37	2	1134-1876-01	Rear Axle Mounting			
38	2	1134-1875-01	Bushing			
39	4	9739-0831-22	Nut			
40	4	9959-0820-16	Screw			
50	1	1134-1925-02	Gear Shifter			
51	1	1134-1981-01	Shift Lock			
52	1	9699-0060-02	Washer			
53	1	9987-5016-16	Screw			
54	1	1134-1916-01	Stop Plate			
55	2	9942-0816-16	Screw			
55	2	9945-0816-16	Screw			




Electrical System

Ref.nr.	Antal	Komponentkode	Beskrivelse	Noter	From	Op til
1	1	1134-3251-02	Bracket			
2	1	9959-0612-16	Screw	L = 12 mm		
2	1	9959-0616-16	Screw	L = 16 mm (US, CA)		
3	2	9739-0631-22	Nut			
4	1	1134-3156-02	Switch			
5	1	9997-0625-16	Screw	L = 25 mm		
5	1	9997-0630-12	Screw	L = 30 mm		
6	1	1134-3551-01	Attachment	2841, 2842, 2843		
7	1	1134-3156-01	Switch	2841, 2842, 2843		
12	1	1134-3204-01	Cable Holder			
13	1	1131-1455-00	Battery Cable (-)			
14	1	1134-0234-01	Battery Cable (+)			
15	1	1134-2310-01	Guard Cap (+)			
16	1	1134-1594-01	Panel			
17	1	1134-1814-01	Starter Switch Assy.			
18	1	1134-2853-01	Washer			
19	1	1134-2852-01	Nut			
20	1	1134-2848-01	Ignition Key			
21	1	1134-1922-01	Battery Plate			
22	1	1134-3621-01	Harness			
22	1	1134-3622-01	Harness	2841, 2842 (US, CA)		
23	1	1134-3623-02	Interlock Module			
24	1	1134-2962-01	Solenoid			
25	2	9794-5131-02	Nut			
26	4	9849-8009-16	Screw			
27	1	9942-0612-16	Screw			
28	2	9739-0631-22	Nut			
29	2	9959-0612-16	Screw			
30	1	9400-0086-00	Battery			
31	1	1134-2333-01	Battery Pad			
32	1	9400-0064-02	Battery Holder			
33	1	1134-3300-01	Battery Acid	2 x 0.85 liter		
34	2	9699-0060-02	Washer			
35	1	9747-0631-02	Lock Nut			
36	1	9795-3531-02	Nut			
45	1	9400-0275-00	Terminal Contact			
46	1	9400-0276-00	Terminal Plug			




Steering

Ref.nr.	Antal	Komponentkode	Beskrivelse	Noter	From	Op til
1	4	1134-0041-01	Bushing			
2	1	1134-3022-01	Bracket			
3	3	1134-3022-01	Bracket			
4	2	1134-9025-01	Steering Pulley	Sats 2 st/kit of 2		
5	4	9942-1030-16	Screw			
6	1	1134-9023-01	Steering Wire			
7	1	1134-1310-01	Spring			
8	1	9699-0090-02	Washer			
9	1	9747-0831-02	Lock Nut			
10	1	9959-0816-16	Screw			
11	1	1134-2390-01	Steering wheel			
20	1	1134-1424-01	Steering Rod			
21	1	1134-1933-01	Steering Pulley			
22	1	9595-0262-00	Locating Pin			
23	2	1134-1901-01	Bearing			
30	1	1134-3538-01	Rear weight (no spare	2841, 2842, 2843		
31	2	9997-1080-12	Screw			
32	2	9699-0035-02	Washer			
40	1	1134-0341-01	Washer			
41	2	1134-3247-02	Tie Rod			
42	1	1134-1428-01	Spindle Lh			
43	1	1134-1428-02	Spindle Rh			
44	1	1134-1500-02	Steering Pulley			
45	1	1134-9024-01	Bearing	Sats 4 st/kit of 4		
46	1	1134-1583-01	Shaft For Steering Pulley			
47	1	1134-1634-01	Rear axle			
47	1	1134-1634-02	Rear axle	2841, 2842, 2843		
48	2	9501-0500-00	Grease Dispenser			
49	3	9650-0020-04	Circlip			
50	2	9699-0088-02	Washer			
51	4	9747-0831-02	Lock Nut			
52	2	9699-0028-02	Washer			
53	4	9997-0825-16	Screw			
54	1	9501-0500-00	Grease Dispenser			
55	1	9650-0020-04	Circlip			
56	1	9699-0088-02	Washer			
57	2	1134-2669-02	Rim W.Bearings			
58	1	1134-9026-01	Bearing	Sats 4 st/kit of 4		
59	2	9545-0117-00	Tyre	13 x 5.00-6		
60	2	9545-0500-00	Valve Assy.			
61	2	1134-0341-01	Washer			
62	2	9650-0020-04	Circlip			
70	1	9595-0262-00	Locating Pin			
71	1	9699-0103-02	Washer	0.5 mm		
71	1	9699-0114-02	Washer	1.0 mm		



Seat

Ref.nr.	Antal	Komponentkode	Beskrivelse	Noter	From	Op til
1	1	1134-0015-00	Seat spring			
2	1	1134-0493-00	Nut			
3	1	1134-2846-01	Tube			
4	1	1134-2847-01	Shaft			
5	1	1134-0022-00	Control Rod			
6	1	1134-0050-00	Seat Rod			
7	2	1134-1650-01	Tie Bar			
8	1	1134-1652-01	Spring			
9	1	1134-3618-01	Seat Attachment-R.H.			
10	1	1134-3618-02	Seat Attachment-L.H.			
11	1	1134-1883-01	Axle			
12	1	1134-2163-01	Rod			
13	1	1134-2166-01	Spacer			
14	1	1134-2454-01	Shaft			
15	2	9672-0006-02	Lock washer			
16	2	9672-0004-02	Starlock			
17	4	9675-0017-02	Starlock			
18	2	9799-0831-02	Nut			
30	1	1134-0800-06	Seat Sears Sa 1216 (9407-0003-01) 20			
40	2	1134-2961-01	Seat Adapter			
41	2	1134-1711-01	Knob			
42	2	9699-0062-02	Washer			
43	4	9988-3616-16	Screw			
44	2	9898-0820-16	Screw			



Manual Lifting Device

Ref.nr.	Antal	Komponentkode	Beskrivelse	Noter	From	Op til
0	1	1134-1437-02	Accessory Ricing Device			
1	1	9403-0110-01	Handle			
2	2	9699-0025-02	Washer			
3	1	1134-0583-00	Knob			
4	2	9739-0631-22	Nut			
5	1	1111-0053-00	Spring			
6	1	1134-1889-01	Eye Bolt			
7	1	1134-0859-03	Bar			
8	1	9646-0099-22	Rivet			
9	1	1134-0858-00	Push Rod			
10	1	9675-0008-02	Starlock			
11	1	1134-2911-01	Locking Pawl			
12	1	9675-0012-02	Locking washer			
13	2	1134-2684-01	Bearing			
14	1	1134-0536-00	Locking Plate			
15	2	9739-1031-22	Nut			
16	2	9959-1020-16	Screw			
17	2	9595-0258-00	Locating Pin			
18	1	1134-1604-01	Trippet			
19	1	1134-1884-01	Lifting Shaft			